


Ersatzteilliste

Führungssystem ETR 350 Typ 2





3744N000

Führungssystem ETR 350 Typ 2

Version

03

Dated: 24.01.2024

all prices excl. VAT

Pos.	Description	Ref.	pc.	Pos.	Description	Ref	pc.
1	Column	796UN086	2	45	Screw M4x12	80201494	4
2	Guide bushing	796UN116	1	46	Gear shaft for bevel gear	3744N430	1
3	Hand crank	796UN129	1	47	Parallel pin 5x30	80200627	1
4	Clamping pin 4x24	40600069	1	48	Wing screw M8x25	80201402	1
5	Washer 8,4	80201377	4	49	Flange plate	3744N801	1
6	Screw M8x25	80201145	4	50	Rail connector, compl.	79600117	1
7	Foot, compl.	3744N900	2	51	Clamping plate 2	796UN118	1
8	Foot	7B201205	2	52	Clamping plate 1	796UN117	1
9	Plate with M12	3744N910	4	53	Screw M12x30	40600072	4
10	Screw M12x60	80201473	2	54	Washer 13	80201381	4
11	Washer 13x30x6	40600112	4	55	Allen key SW 4	80430046	1
12	Clamping pin 4x18	40600083	4	56	Plug	80900201	1
13	Nut M10	80201034	2	57	Shim ring 20x28x0,2	80200511	2
14	Screw M10x40	80201113	2				
15	Machine holder, compl.	79600110	1				
16	Machine holder	796UN119	1				
17	Pinion shaft	3744N600	1				
18	Grooved ball bearing 6002 2RS	80410037	2				
19	Retaining ring 14x1	80201318	2				
20	Eccentric	796R3765	2				
21	Bolt	796R3730	2				
22	Nut M12	80201036	4				
23	Grooved ball bearing 6001 2RS	80410036	8				
24	Roller	796R1763	4				
25	Washer 8,4	80201377	4				
26	Nut M8	80201221	4				
28	Gearbox, compl.	3744N40V	1				
29	Gearbox housing	3744N406	1				
30	Screw M5x30	80201175	4				
31	Cap nut M5	40600050	4				
34	Spring lock washer 4	80201301	4				
36	Spacer block	6630F017	1				
37	Retaining ring 28x1,2	80201333	1				
38	Needle sleeve HK1010	80420115	1				
39	Grooved ball bearing 6201 2RS	80410100	1				
40	Gear shaft, compl.	7681551U	1				
41	Retaining ring 32x1,2	80201351	1				
42	Bevel gear	6630F018	1				
43	Gearbox seal	6630F016	1				
44	Housing cover	6630F013	1				